Showcase your liquid cooling capabilities with our NeuCool[™] Thermal Simulation Rack

The Thermal Simulation Rack (TSR) incorporates our highly engineered two-phase, direct-to-chip NeuCool in-rack system in addition to unique power, control, and measurement elements



Load Simulation Sleds (LSS) (up to 10 @ 5kW each)



iCDU (pumps, condenser & electronics)

Thermal Simulation Rack "Thermal banking" for liquid cooling

- Cost-effective rack-level solution to simulate a high-density server load
- Simple control and monitoring through a laptop with custom Labview GUI
- Optimized for our environmentally friendly dielectric fluid
- Load Simulation Sleds (LSS) provide up to 5kW of thermal load in 1U at fraction of AI-HPC server costs
- Rack thermal load is modular and capable of up to 50kW/rack

Load Simulation Sled (LSS) Specifications

- 1U chassis that mounts to standard 19" rails
- Each LSS has (5) thermal test vehicles (TTVs) with NeuCool Vaporators
- Each TTV generates up to 1kW of heat in the footprint of a single CPU
- Industry-leading density of 5kW per 1U LSS
- Allows testing NeuCool system with heat flux and density exceeding highest performance GPU and CPU servers on the market
- "TSR-30" and "TSR-50" configurations have up to (6) or (10) LSSs, respectively
- (1) LSS comes equipped with transparent lid vaporators to demonstrate phase change

ACCELSIUS

1835 Kramer Lane Suite 2-180 Austin, TX 78758

www.accelsius.com

info@accelsius.com

©2024 Accelsius LLC. All Rights Reserved. V1002

Product details subject to change without notice. Trade names, marked or not, are the property of the registered owners.

The NeuCool Thermal Simulation Rack is supported by the following components:

Power Distribution Sled

- Contains (2) power controllers that manage and distribute electrical power to the LSSs
- Each 3U power sled distributes up to 30kW of power across (6) LSSs
- Power for each LSS is monitored and controlled individually, via a PC-based application
- (2) 3-phase 208-240 VAC power feeds recommended; can accommodate lower voltage or single-phase connections with a reduction in total power capacity

Instrumentation Sled

- 3U sled consists of a rackmount data acquisition (DAQ) system for thermocouple measurement
- Interfaces with a PC using to monitor and record temperatures from up to 125 thermocouples from the TTV Sleds or other key thermal measurement points in the user's facility
- Includes a measurement and control application built in LabVIEW. Data can also be accessed via the user's own LabVIEW, Python, or other language application

Laptop Tray

- 2U tray and software provided for laptop (laptop provided by customer)
- GUI-based application displaying the recorded temperatures for each TTV, as well as power/heat measurements for each LSS
- The power output by the **Power Distribution Sleds to** the TTVs can be controlled by the user via the application

...and be sure to ask us about our two 42U rack configurations!

TSR-30

- Up to 30kW coolable heat
- Up to (6) LSS @ 5kW each
- (1) 3U DAQ Instrumentation Sled
- (1) 3U Power Distribution Sled
- (1) LabVIEW GUI (for control & monitoring)
- (1) 2U Laptop Tray (laptop not provided)
- Can scale to higher rack load by adding 2phase NeuCool servers (up to 16U available)

- **TSR-50**
- Up to 50kW coolable heat
- Up to (10) LSS @ 5kW each
- (1) 3U DAQ Instrumentation Sled
- (2) 3U Power Distribution Sled
- (1) LabVIEW GUI (for control & monitoring)
- (1) 2U Laptop Tray (laptop not provided)
- Can scale to higher rack load by adding 2phase NeuCool servers (1U available)

...we also have extreme density options up to 250kW/rack!

- Test & demonstrate row-mounted CDUs
- Scalable capacity from 50 to 250kW
- Monitor & control all LSSs individually or simultaneously

Commercial Terms

- This is a demo only; not for re-sale
- No regulatory or environmental certifications
 Requires access to facility water (FWS)
- Designed for in-lab testing

ACCELSIUS

1835 Kramer Lane Suite 2-180 Austin. TX 78758

www.accelsius.com

info@accelsius.com

©2024 Accelsius LLC. All Rights Reserved. V1002

Product details subject to change without notice. Trade names, marked or not, are the property of the registered owners.